



THE DECK THICKNESS IS MEASURED FROM THE BOTTOM OF THE DECK PLATE #11 TO THE TOP OF THE BOTTOM DECK PLATE. THE STANDARD IS 4". IT IS THIS 4" THAT LOCATES THE POSITION OF THE CHAIN STRIPPER # 30. IF THE 4" FIGURE IS NOT KEPT BY EITHER BLOCKING BELOW OR ABOVE THE DECK THE ABOVE PARTS WILL NOT FIT TOGETHER PROPERLY. IF YOUR DECK SPACE IS SMALLER THAN 4" YOU CAN BLOCK TO THE 4" FIGURE. IF YOU NEED MORE DECK SPACE YOU NEED A SPECIAL DECK THICKNESS WINDLASS. THIS MUST BE KNOWN BEFORE HAND AS THERE IS NO WAY TO ADD IT LATER.